


CONN6
USB Plug Type A

Host

Chipflasher

CONN7
USB Plug Type A

CONN8
USB Plug Type A



Y-USB Power Cable

Zerocat Chipflasher

Flash free firmware, kick the Management Engine.
[git://zerocat.org/zerocat/projects/chipflasher](https://zerocat.org/zerocat/projects/chipflasher)

TITLE			
FILE:	testboard-page12.sch	REVISION:	v2.0.2-0-4270742b1
PAGE	OF	DRAWN BY:	kmx